http://www.hynux.net

HARYOURG NUX

STS Series

SAFETY INFORMATION

. End of unused lead wire must be insulated.

Suffix code

1

2

3

4

5

М

Ρ

1

R Red

Υ

G

В Blue White

W

a break down of product

a break down of product.

transformation in shape,

Model

Rated voltage

Number of stacks

Mount

Color

* 12 V is a custom-made Example)

SPECIFICATION

Model

Color

Drive

Powerconsumption

Protection class

× 12 Visacustom−made,

STS 060 - C 51 - 2 - P - R Y

STS 060 - C 51 - 2 - L - R G

bracket, 1 stacks RED, 2 stacks YELLOW

bracket, 1 stacks RED, 2 stacks GREEN

(Fuse rated : 250 V 0,2 A)

HOW TO ORDER

STS 040, 060, 080

C5

INSTRUCTION MANUAL

Thank you for purchasing HANYOUNG product. Please check whether the product is the exactly same as you ordered. Before using the product, please read this instruction manual carefully.

This product is only suitable for indoor use. Please keep it away from damp place,

. Do not pull wire strongly that is outside of product, it will cause a break down of product

·Please do not change parts of product or do not use other product parts, it will cause

. Contamination by thinner, benzene over lens or top cover will cause a fade in color or

·Power switch and fuse are not attached to this product. So please install them outside,

LED Sign Tower

Mounting Bracket

Pipe Bracket

L type Bracket

R, Y, G, B, W in order

⇒ Ø60 SIGN TOWER, Continuous light, 24 V a,c / d,c 50 - 60 Hz, 2 stacks, Pipe

→ Ø60 SIGN TOWER Continuous light, 24 V a.c / d.c 50 - 60 Hz, 2 stacks, L type

STS 040, 060, 080

RED, YELLOW, GREEN, BLUE, WHITE 5 color

Relay, NPN, PNP Transistor Open Collector Drive 24 V d.c/a.c

1.1 W per each lamp, max, 7 W for 5 stacks F type

IP54

1 Light

2 Light

3 Light

4 Light 5 Liaht

Yellow

Green

24 V d.c / ac 50 - 60 Hz


Desc ript ion

· Please use correct violtage. Over voltage will cause a break down of product. •Please refer to Wiring Diagram' when you wire product. Wrong wiring will cause

• Big impact on this product will cause a break down of LED units,


DIMENSIONS -

STS Series





HOW TO INSTALL-

· Fixing must be done in carefully selected place such as horizontal or vertical or vertical surface that are not shaking too much,



WIRING DIAGRAM





PNP TRANSISTOR OPEN COLLECTOR DRIVE LAMP RED (RED) LAMP YELLOW (YELLOW) LAMP GREEN (GREEN) Continuous Light LAMP BLUE (BLUE) LAMP WHITE (WHITE POWER Ģ 24 Vd.c POWER (BLACK)

HEAD OFFICE

1381-3, Juan-Dong, Nam-Gu Incheon, Korea

TEL: +82-32-876-4697 FAX: +82-32-876-4696